

A/120/VTI Piezo-Tronic IEPE Accelerometer Case Isolated

10mV/g up to 1V/g ±10%

26.6gm

Std temp 125°C

The A/120 range of general purpose Konic shear IEPE vibration transducers offer a wide range of mounting, connectors and sensitivities all using DJB's unique and technically superior Konic shear design of piezoelectric ceramic sensor. Offering anything from 10mV/g up to 1V/g output within the same size accelerometer body it is perfectly suited to applications from vibration shaker control and delicate testing through to industrial machine monitoring.

The A/120/VTI offers a case isolated construction with a top entry 10/32 microdot connector

Using a wide range of IEPE signal conditioning levels the A/120 can interface directly to a wide range of commercially available vibration spectrum analyzers and data acquisition systems as well as in our own VB/01 & VB/02 and CV9 signal conditioners which offer a range of amplification options.

Note:

Voltage sensitivities shown are standard. We offer a wide range of sensitivities on request and recommend that applications are evaluated to determine the requisite sensitivity.





ISO 9001 - 00025363



A/120/VTI





A/120/VTI Piezo-Tronic IEPE Accelerometer Case Isolated



10mV/g up to 1V/g ±10%

26.6gm

Std temp 125°C

	Metric		Imperial	
Voltage Sensitivity ±10%	1.0mV/(m/s ²)	10.2mV/(m/s²)	10mV/g	100mV/g
Resonant frequency	28 kHz			
Typical Frequency±5%Response±10%	1Hz – 7kHz 0.7Hz – 8kHz			
Cross Axis error	≤5%			
Insulation Resistance	10 ¹⁰ Ω at 250V			
Temperature Range	-50/+125°C		-58/+257°F	
Voltage sensitivity deviation (20°C/68°F)	-5% @ -50°C +5% @ +125°C		-5% @ -58°F +5% @ +257°F	
Supply voltage	15/35 V DC			
Supply current	2/20mA			
Bias voltage	10/14 VDC			
Output Impedance	≤100Ω			
Broadband resolution (grms)	0.005	0.003	0.005	0.003
Amplitude linearity (%FS)	≤1%			
Settling time within 10% bias	<5 secs			
Shock Limit	49,033m/s ²		5000g	
Saturation Limit, equiv .g	4903m/s ²	490m/s ²	500g	50g
Base Strain Sensitivity	≤0.001g/µ strain			
Case material	Stainless Steel 303			
Mounting	Base tapped hole, 10-32 UNF x 4mm deep		Base tapped hole, 10-32 UNF x 0.16 deep	
Weight	26.6g		0.94oz	
Case seal	Welded hermetic connector		Welded hermetic connector	
Connector	10-32 UNF Microdot top entry			
Size	14.3 (A/F) x 27.5mm		0.562in (A/F) x 1.084in	

Please note: For information and reference only. Data should not be used as pass / fail criteria for calibration purposes

DJB Instruments (UK) Ltd Finchley Avenue, Mildenhall, Suffolk IP28 7BG

t Tel Email Web

+44 (0)1638 712 288 sales@djbinstruments.com www.djbinstruments.com

DJB Iss.7 2020



A UK company with UK-based manufacturing, assembly and calibration in-house.

ISO 9001 - 00025363