

AT/11 Triaxial Piezo-Tronic **IEPE** Accelerometer

18.9gm

1mV/g up to 100mV/g ±10%

Std Temp 125°C



The AT/11 has been developed primarily for the Modal Analysis and Structural test marketplace with particular focus on the Automotive and Aerospace markets. It can be used as a direct replacement for the B&K 4506 accelerometer, fitting into the same clip mounting.

The slotted sides and a slotted base allow it to be mounted on 5 of its faces by sliding into the accompanying clip. Users can then mount the clips using normal glue methods and slide the accelerometers in and out of the clip as required. This ensures perfect repeatability for tests without the need for leaving the accelerometer in situ. In addition, for large channel count testing, all accelerometers can be mounted in the same orientation making software set up easier.

Manufactured in Titanium for low mass and long life, the AT/11 has three individual Konic shear® sensing elements internally mounted in the three orthogonal axes; this provides excellent performance in each axis with minimal cross axis effects.







Z Axis

Please note: For information and reference only. Data should not be used as pass / fail criteria for calibration purposes

DJB Instruments (UK) Ltd Finchley Avenue, Mildenhall, Suffolk IP28 7BG

+44 (0)1638 712 288 Email sales@djbinstruments.com Web www.djbinstruments.com

ISO 9001 001 ISO 9001 - 00025363

A UK company with UK-based manufacturing, assembly and calibration in-house.

Tel

DJB Iss.7.2020



AT/11 Triaxial Piezo-Tronic IEPE Accelerometer

1mV/g up to 100mV/g ±10%

18.9gm Std Temp 125°C







	Metric			Imperial		
Voltage Sensitivity @20°C ±10%	0.1m/s ²	1.02m/s ²	10.2m/s ²	1mV/g	10mV/g	100mV/g
Resonant frequency	Z Axis 33 kHz X/Y Axis 25 kHz					
Typical Frequency Response±%5(X/Y/Z Axis)±10%	1Hz - 5kHz 0.7Hz - 6kHz	1Hz - 5kHz 0.7Hz-6kHz	2Hz - 5kHz 1Hz - 6kHz	1Hz - 5kHz 0.7Hz-6kHz	1Hz - 5kHz 0.7Hz-6kHz	2Hz - 5kHz 1Hz - 6kHz
Cross Axis error	≤5% max					
Temperature Range	-50/+125°C			-58/+257°F		
Voltage sensitivity deviation	-5% @ -50°C			-5% @-58°F		
(20°C / 68°F)	+5% @+125°C			+5% @+257°F		
Supply voltage	15/ 35 V DC					
Supply current	2/20 mA					
Bias voltage (20°C / 68°F)	9/14 V DC					
Amplitude Linearity (%FS)	≤1%					
Broadband resolution	0.002grms					
Output impedance	≤100Ω					
Settling time within 10% bias	<3 sec					
Max continuous accn.g sine	49033m/s ²			5000g		
Saturation Limit	49033m/s ²	4903m/s ²	490.3m/s ²	5000g	500g	50g
Base Strain Sensitivity	0.001g/µ strain					
Case material	Titanium Grade 2					
Mounting	Adhesive or Clip Mounting					
Weight	18.9g 0.67oz					
Case seal	Welded hermetic connector					
Size	17 x 17 x 17mm 0.67 x 0.67 x 0.67in					
Connector	4 pin ¼ - 28 UNF					

Please note: For information and reference only. Data should not be used as pass / fail criteria for calibration purposes

DJB Instruments (UK) Ltd Finchley Avenue, Mildenhall, Suffolk IP28 7BG

Tel+44 (0)1638 712 288Emailsales@djbinstruments.comWebwww.djbinstruments.com

DJB Iss.7 2020



A UK company with UK-based manufacturing, assembly and calibration in-house.

ISO 9001 - 00025363